Precautions for the use of UV floodlights

boot:

- (1) Close the external circuit switch.
- (2) Turn on the main switch, at this time, the UV light of the power supply will turn on and start at

the same time.

(3) Turn on the UV light switch, and the UV light will be on at this time. After about three minutes, the UV light reaches its peak (ultraviolet rays are the strongest). The UV light source can be irradiated on the object to be irradiated.

shutdown:

- (1) Turn off the UV light switch, and the UV light will go out at this time.
- (2) When the temperature in the UV light box drops slightly (below about 50°C), turn off the main switch.
- (3) Turn off the external power supply.
- Precautions: This power supply is designed for portable use, and its UV lamp installation leaks outside. Please pay attention to the following points:
- (1) Since ultraviolet rays are harmful to the human body, it is strictly forbidden to directly irradiate the eyes and skin to avoid burns.
- (2) When the lamp body is not in use, it should be placed in a suitable place to prevent hard objects from hitting the surface of the lamp, so as not to damage the lamp body.
- (3) When the lamp body is in use, it is necessary to prevent hard objects from hitting the surface. At this time, the temperature of the lamp body is high, so burns should be prevented.
- (4) When the light source is in use, it is strictly forbidden to open the power control shell to prevent electric shock.
- (5) It is recommended to keep ventilation in the use environment to prevent overheating and damage to the light source of the lamp.
- (6) It is strictly forbidden to use UV lamps in explosive areas.
- (7) If it is necessary to move the location where the UV light source is used, the UV lamp and power supply should be turned off first, and then turned on in sequence after moving to a new location.
- (8) Do not disassemble the UV-LED irradiation may cause UV light leakage and reduce the waterproof function.
- (9) When cleaning regularly, please do not use thinner, volatile oil, acetone, kerosene, etc. You can use a soft cotton cloth to spot a small amount of ethanol and wipe carefully.
- (10) Please use the machine in a cool, dry, ventilated environment without high magnetic field or high electric field
- (11) Please use the DC power supply specially configured by our factory for the source adapter
- (12) Do not open it privately to prevent leakage.